SVC4

4-zone stereo volume control

You may use 2 loudspeakers per zone.

The SVC4 uses internal resistors. In this way you can adjust (or switch off) the volume in one zone, without influencing the volume in the other zones.

Built-in in a compact black metal housing, such is very durable due to the step-by-step volumes.

gives you the possibility to adjust (or switch off) the volume in 4 different zones. SVC4 can be used with a standard HiFi amplifier.

The SVC4 is a unique multiple stereo volume control. It

In case you only want to adjust 2 zones, you can use traditional 8 Ohm loudspeakers. If you want to adjust the volume in 3 to 4 zones, you have to use 16 Ohm loudspeakers.

TECHNICAL SPECIFICATIONS

stereo/mono	Stereo	impedance 2-zones in ohms	8
impedance 4-zones in ohms	16	max. power in watts	4 x (2 x 40)
applicable 100V	No	applicable low impedance	Yes
steps	6 + on/off switch	24 volt priority relais	No
connector type	Terminal 20-pole	max. cable in mm ²	2.5
width in mm	210	height in mm	46
depth in mm	185	weight in gr	1100
Net weight product (kg)	1,15		

MORE PICTURES



